Applied Signal Processing Lecture 14

Tomas McKelvey

Department of Electrical Engineering Chalmers University of Technology

Outline

- Signal Detection
 - Pulsed radar system
 - Signal Matched Filter
- Quantization errors
- Efficent implementation of decimation and intperpolation
 - Polyphase decomposition of FIR filters

Pulsed radar

Principle of operation: Measure *time difference* between transmitted and received pulse.

- Transmitter
 - Pulse generation (DAC)
 - Modulation
 - Amplification (PA)
- Receiver
 - Low Noise Amplification (LNA)
 - Demodulation
 - Sampling
 - Pulse detection

Pulse detection

A hypothesis test problem:

$$\mathcal{H}_0$$
: $\mathbf{x} = \mathbf{s} + \mathbf{v}$
 \mathcal{H}_1 : $\mathbf{x} = \mathbf{v}$

where

measured signal:
$$\mathbf{x} = \begin{bmatrix} x(0) & x(1) & \cdots & x(N-1) \end{bmatrix}^T$$
 signal to detect: $\mathbf{s} = \begin{bmatrix} s(0) & s(1) & \cdots & s(N-1) \end{bmatrix}^T$ measurement noise: $\mathbf{v} = \begin{bmatrix} v(0) & v(1) & \cdots & v(N-1) \end{bmatrix}^T$

We assume v(k) to be a white, zero mean stochastic process with variance σ_v and uncorrelated with s(k). Shape of s is known.

A linear detector is

$$\mathbf{h}^*\mathbf{x} = \sum_{k=0}^{N-1} h^*(k)x(k) \begin{cases} > \alpha & \text{Select } \mathcal{H}_0 : \text{ Signal is detected} \\ \leq \alpha & \text{Select } \mathcal{H}_1 : \text{ No signal is detected} \end{cases}$$

How to select **h** and the threshold α .

Signal matched filter

To maximize the performance of the detector we can maximize the size of $|\mathbf{h}^*\mathbf{x}|$ when the signal is present compared to when the signal is not present:

$$\frac{\left.\mathsf{E}\left|\mathsf{h}^*\mathsf{x}\right|^2\right|_{\mathcal{H}_0}}{\left.\mathsf{E}\left|\mathsf{h}^*\mathsf{x}\right|^2\right|_{\mathcal{H}_1}} = \frac{\left|\mathsf{h}^*\mathsf{s}\right|^2 + \mathsf{E}\left|\mathsf{h}^*\mathsf{v}\right|^2}{\left.\mathsf{E}\left|\mathsf{h}^*\mathsf{v}\right|^2} = \frac{\left|\mathsf{h}^*\mathsf{s}\right|^2}{\sigma_{\nu}^2|\mathsf{h}^*\mathsf{h}|} + 1$$

Since the Cauchy-Schwartz inequality for vectors state that

$$|\mathbf{h}^*\mathbf{s}|^2 \le |\mathbf{h}^*\mathbf{h}||\mathbf{s}^*\mathbf{s}|$$

the fraction above is maximized when we select h = s.

The filter is *matched* to the pulse shape.

Tuning the detector

$$\mathbf{h}^*\mathbf{x} = \begin{cases} > \alpha & \text{Select } \mathcal{H}_0 : \text{ Signal is detected} \\ \leq \alpha & \text{Select } \mathcal{H}_1 : \text{ No signal is detected} \end{cases}$$

The performance of a detector is given as two metrics:

Probability of detection (PD) The probability that the detector detects a signal given that *the signal exists*.

Probability of False alarm (PFA) The probability that the detector detects a signal given that *there is no signal*.

The threshold α will give a balance between these two metrics.

The detector $\mathbf{h} = \mathbf{s}$ maximizes the PD given a fixed PFA.

Detection is FIR filtering

We have

$$\mathbf{h}^H \mathbf{x} = \sum_{k=0}^{N-1} h^*(k) x(k) = \sum_{k=0}^{N-1} h_{det}(k) x(N-1-k)$$

if


$$\mathbf{h}_{\mathsf{det}} = \begin{bmatrix} h^*(N-1), & h^*(N-2), & \cdots, & h^*(0) \end{bmatrix}^T$$

The detector is a filter with the conjugate reverse signal as impulse response.

For streaming data the detector is used in a sliding window and can also be seen as the output of a FIR convolution. Also the name *correlator* is used.

Quantization Errors

In the sampling step that analog signal is converted to a finite representation encoded with ${\it B}$ bits. This is called quantization.



The output of the ADC can be described by

$$x_q(n) = x_c(n\Delta t) + q(n) = x(n) + q(n)$$

where $x_q(n)$ is the quantized signal and q(n) is the difference between the true sample x(n) and the output $x_q(n)$.

Quantization errors

Assume the quantizer is uniform with B bits. Then it has 2^B different levels between amplitudes $\pm A$.

Then the quantization step is $S_q = \frac{2A}{2^B-1} \approx \frac{2A}{2^B}$ and the quantization error is bounded by $|q(n)| \leq \frac{S_q}{2} = \frac{A}{2^B}$.

Although completely determined by the value of the input signal, a good model of the error is to assume q(n) is a zero mean random variable with a uniform distribution in the interval $\left[-\frac{A}{2^B},\frac{A}{2^B}\right]$. The variance of the quantization error is

$$\sigma_q^2 = \int_{-A/2^B}^{A/2^B} x^2 \frac{1}{2A/2^B} \, dx = \frac{1}{3} \frac{A^2}{2^{2B}}$$

Quantization SNR

Relate the level of quantization to a sinusoidal signal with maximum amplitude A.

The power of the sinusoidal signal is $A^2/2$. The signal to noise ratio (SNR) or *dynamic range* is given by

$$R_D = 10 \log_{10} \frac{\frac{A^2}{2}}{\frac{A^2}{3 \times 2^{2B}}} = 10 \log_{10} \frac{3}{2} + 10 \log_{10} 4^B = 1.76 + 6.02B \quad \text{[dB]}.$$
(1)

- Every extra bit will provide an increased dynamic range with 6.02 dB.
- The quantization noise will have a constant power spectral density and will correspond to what is commonly referred to as a noise floor in the spectral domain.